

CREATING TOMORROW'S SOLUTIONS

GENIOPLAST

PLASTICS I PERFORMANCE ADDITIVES

KEEP COOL WITH INTEGRATED FIRE PROTECTION

Case Study: Aluminum Composite Panels

GENIOPLAST® PELLET S IMPROVES FLAME RETARDANCY IN ALUMINUM COMPOSITE PANELS (ACPs)

Aluminum composite panels (ACPs) used on building exteriors have a plastic core that contains fire-retardant (FR) fillers. To make these compounds easier to process, a silicone additive, GENIOPLAST[®] Pellet S, is added.

Aluminum composite panels consist of 2 aluminum sheets bonded with an adhesive to a non-aluminum core. To ensure that the aluminum panels do not act as a cold bridge and encourage heat loss, an insulating plastic layer is sandwiched between two aluminum layers. The non-aluminum core consists of a highly mineral filled polyolefin compound which is highly flame retardant. ACPs are increasingly used to construct buildings. In the event of a fire, the aluminum panels increase heat rejection so that fire propagation is stopped.

Requirements

- Flame retardancy is a critical factor in many applications, e.g. construction
- Non-toxic materials (HFFR, LSOH)
- 80 85% mineral filler (ATH/MDH) is required to pass the highest flame classification A1

GENIOPLAST[®] Pellet S Improves the Manufacturing and Processing of ACPs as well as their Mechanical Properties

ACPs are manufactured in several steps (separate or combined). The compounding step of the non-metallic core material, which is based on an HFFR compound, may involve some difficulties in flow behavior, which can cause die drool on the extruder die. GENIOPLAST® Pellet S simplifies processing (lower torque), improves the flow properties (higher MFI value) of the highly mineral-filled PE compound even at dosages of less than 1%. In addition, the mechanical properties of the PE compound are improved. As a result,

GENIOPLAST® is a registered trademark of Wacker Chemie AG.

there is less die build-up and there are fewer cleaning steps. There is no influence on adhesion to the other layers obtained. GENIOPLAST[®] Pellet S has to be compounded together with the PE and mineral filler.



GENIOPLAST[®] Pellet S has a positive impact on several material characteristics.

Adding GENIOPLAST® Pellet S Improves Fire Performance in ACPs

Cone calorimetry – an important test method for fire performance – shows that when a compound containing GENIOPLAST® Pellet S combusts, the peak heat, total heat and smoke release rate decrease. A dosage level of 2% is recommended. In order to obtain the optimum compounding level, GENIOPLAST® Pellet S is dry-blended with the polymer base resin and fed in a gravimetric feeder. The FR filler is dosed separately in a gravimetric dosing system in the feeder. Material ATH/MDH HFFF compounds

Additive GENIOPLAST® Pellet S

Dosage

Application

PE core layer of ACPs

Key Benefits

- Improved fire retardancy (lower smoke release rate)
- Simplified processing (lower torque)
- Better flow behavior
- Improved mechanical properties
- Reduced die build-up
- Fewer cleaning steps





Wacker Chemie AG Hanns-Seidel-Platz 4 81737 Munich, Germany Phone +49 89 6279-1741 info@wacker.com

www.wacker.com

www.wacker.com/socialmedia



The data presented in this medium are in accordance with the present state of our knowledge but do not absolve the user from carefully checking all supplies immediately on receipt. We reserve the right to alter product constants within the scope of technical progress or new developments. The recommendations made in this medium should be checked by preliminary trials because of conditions during processing over which we have no control, especially where other companies' raw materials are also being used. The information provided by us does not absolve the user from the obligation of investigating the possibility of infringement of third parties' rights and, if necessary, clarifying the position. Recommendations for use do not constitute a warranty, either express or implied, of the fitness or suitability of the product for a particular purpose.