

SILRES[®] BS CREME D



Silane Cremes

SILRES[®] BS CREME D is an aqueous, solvent-free injection product in the form of a silane-based cream. It is used to prevent rising damp (horizontal barrier).

Properties

- silane-based, solvent-free cream
- ready to use
- optimized for pressureless application
- easy to use
- suitable for high moisture contents

CSTC certificates confirm the suitability of SILRES[®] BS CREME D for this kind of application.

Technical data

General Characteristics

Property	Condition	Value	Method
Active substance	-	approx. 80 wt. %	-
Appearance	-	white to yellowish creme	-
Density	25 °C 1013 hPa	approx. 0.9 g/cm ³	-
Flash point	-	64 °C	ISO 3679

These figures are only intended as a guide and should not be used in preparing specifications.

All the information provided is in accordance with the present state of our knowledge. Nonetheless, we disclaim any warranty or liability whatsoever and reserve the right, at any time, to effect technical alterations. The information provided, as well as the product's fitness for an intended application, should be checked by the buyer in preliminary trials. Contractual terms and conditions always take precedence. This disclaimer of warranty and liability also applies particularly in foreign countries with respect to third parties' rights.

Compliance

[Full compliance info plus certificates can be downloaded from the product website.](#)

Approvals SILRES® BS Creme D

Applications

- Hydrophobic Impregnation
- Impregnation of New and Existing Buildings
- Masonry Dampproofing

Application details

SILRES® BS CREME D is a cream used as a water-repellent injection agent to prevent rising damp in masonry. The cream is injected as evenly as possible into the masonry or mortar joints without pressure via drilled holes. SILRES® BS CREME D can be used even when the moisture content is high. However, pressurized injection of water-dilutable silicone microemulsion concentrates (SILRES® BS SMK) is preferred whenever very thick walls exhibit a high moisture content.

Inject ready-to-use SILRES® BS CREME D from tubular bags or other suitable packaging into the holes drilled into the masonry. The holes are usually drilled at ground height (outdoors) or at floor height (indoors). Select the injection tube to match the hole diameter and insert it as far into the hole as possible. To fill the hole as completely as possible, squeeze the cream out slowly while withdrawing the injection tube.

The hole diameters and the distance between the holes may vary, as they depend on the construction material's absorbency. This makes it possible to take account of the various types of masonry (such as solid brickwork and cavity walls).

In the case of homogeneous masonry, it is generally advisable to space the holes 8 – 12,5 cm apart and to choose a diameter of 12 - 20 mm, depending on the specifics of each building. The drilled hole should be approx. 2 cm less than the width of the wall. Preferably drill the injection holes horizontally - each hole starting out from a masonry joint. Fill the holes completely with SILRES® BS CREME D. This is a very good way to impregnate the absorbent joint zones. Before injecting the cream, always blow drilling powder out of the holes.

If thick masonry exhibits a high moisture content, we recommend the pressurized injection of silicone microemulsion concentrates (SILRES® BS SMK).

Packaging and storage

Storage

The "Best use before end" date of each batch is shown on the product label. Storage beyond the date specified on the label does not necessarily mean that the product is no longer usable. In this case however, the properties required for the intended use must be checked for quality assurance reasons.

Safety notes

Comprehensive instructions are given in the corresponding Material Safety Data Sheets. They are available on request from WACKER subsidiaries or may be printed via WACKER web site <http://www.wacker.com>.

QR Code SILRES® BS CREME D



For technical, quality or product safety questions, please contact:

Wacker Chemie AG, Hanns-Seidel-Platz 4, 81737 Munich, Germany
productinformation@wacker.com, www.wacker.com

The data presented in this medium are in accordance with the present state of our knowledge but do not absolve the user from carefully checking all supplies immediately on receipt. We reserve the right to alter product constants within the scope of technical progress or new developments. The recommendations made in this medium should be checked by preliminary trials because of conditions during processing over which we have no control, especially where other companies' raw materials are also being used. The information provided by us does not absolve the user from the obligation of investigating the possibility of infringement of third parties' rights and, if necessary, clarifying the position. Recommendations for use do not constitute a warranty, either express or implied, of the fitness or suitability of the product for a particular purpose.