


## CREATING TOMORROW'S SOLUTIONS



PLASTICS I PERFORMANCE ADDITIVES

# POWER UP YOUR CABLES

Case Study: Wires & Cables

# GENIOPLAST<sup>®</sup> PELLET S FOR WIRES AND CABLES

The trend toward halogen-free flame retardants (HFFRs) has placed new processing demands on wire and cable manufacturers. The new compounds are heavily loaded and can create issues with die drool, poor surface quality, and pigment/filler dispersion. Incorporating GENIOPLAST<sup>®</sup> Pellet S significantly improves the material flow, extrusion process, and creates a synergistic effect with flame-retardant fillers.

#### Adding 0.1 – 1% of GENIOPLAST® Pellet S

- Improved processing and flow
- Less extruder torque
- Lower die pressure
- Reduced die drool and melt fracture
- Faster throughput
- Better melt flow

#### Adding 1 – 3% of GENIOPLAST<sup>®</sup> Pellet S

- Improved surface lubricity and slip
- Lower coefficient of friction
- Better abrasion resistance
- Better surface touch and feel
- Better mechanical properties
- Better synergy with flame retardants

	Without Additive	+0.5% GENIOPLAST <sup>®</sup> Pellet S	+1% GENIOPLAST <sup>®</sup> Pellet S
LDPE/ATH (60%)			
LOI [% 0 <sub>2</sub> ]	26	26	26
UL 94	V-1	V-0	V-0
PP/MDH (60%)			
LOI [% 0 <sub>2</sub> ]	26	30	32
UL 94	V-0	V-0	V-0





	_	

Dosage



Application HFFR compounds for cable jacketing


## **Key Benefits**

- Higher throughput
- No die drool
- Better surface properties
- Better flame retardancy

GENIOPLAST<sup>®</sup> is a registered trademark of Wacker Chemie AG.

In polyolefin-based HFFR compounds containing flame retardant filler, such as aluminum hydroxide (ATH) or magnesium hydroxide (MDH), GENIOPLAST<sup>®</sup> Pellet S acts as char former and can reduce heat release and smoke generation. This benefit is demonstrated in the cone calorimetry graph and data below.

	Reference	+2% GENIOPLAST <sup>®</sup> Pellet S
Time of ignition [s]	68	61
Peak heat release rate [kW/m <sup>2</sup> ]	203	151
Total heat released [MJ/m <sup>2</sup> ]	110	102
Total smoke released [m <sup>2</sup> /m <sup>2</sup> ]	866	313
Burning time [s]	1217	1820







Combustion residue: reference

Combustion residue: +2% GENIOPLAST® Pellet S



Wacker Chemie AG Hanns-Seidel-Platz 4 81737 Munich, Germany Phone: +49 89 6279 -1741 info@wacker.com

www.wacker.com

www.wacker.com/socialmedia



The data presented in this medium are in accordance with the present state of our knowledge but do not absolve the user from carefully checking all supplies immediately on receipt. We reserve the right to alter product constants within the scope of technical progress or new developments. The recommendations made in this medium should be checked by preliminary trials because of conditions during processing over which we have no control, especially where other companies' raw materials are also being used. The information provided by us does not absolve the user from the obligation of investigating the possibility of infringement of third parties' rights and, if necessary, clarifying the position. Recommendations for use do not constitute a warranty, either express or implied, of the fitness or suitability of the product for a particular purpose.

Children and Chi